

Model: Model AG-1		Date: 8-Jun-05	No.: RJ001001
Subject: Firmware Release History		Prepared by: Y. Ohtani	
From: 1st Tech. Support Sec. Service Support Dept.			
Classification:	<input type="checkbox"/> Troubleshooting <input type="checkbox"/> Part information <input type="checkbox"/> Action required <input type="checkbox"/> Mechanical <input type="checkbox"/> Electrical <input type="checkbox"/> Service manual revision <input type="checkbox"/> Paper path <input type="checkbox"/> Transmit/receive <input type="checkbox"/> Retrofit information <input checked="" type="checkbox"/> Other ()		

This RTB has been issued to announce firmware release information.

General Information

Firmware Version	Program No.	Effective Date
6.01	J0015130	April 2005 production

History

Service Card Version	Symptom Corrected
6.01	Other changes: Print speed control is disabled for "High-Speed" mode. Note: As a result, the machine will not decrease the print speed in "High-Speed" mode, even under low-temperature, low-humidity conditions.

Important Notes for When Installing This Firmware:

- This firmware is only for **Model A-G1**. It cannot be used on Model P-G1.
- Install this firmware via a **direct USB connection** between a PC and the printer.
Note: This firmware cannot be installed via a network connection.
- Before you start the installation:
 - Shut down all other foreground applications on the PC.
 - Make sure that the printer main power is ON.
- If the installation fails, execute the ".exe" file again.

Model: All GelSprinter models		Date: 26-Aug-08	No.: RJ007024
Subject: GJ analysis tool		Prepared by: Y.Murata	
From: 1st Tech. Support Sec. Service Support Dept.			
Classification:	<input type="checkbox"/> Troubleshooting	<input type="checkbox"/> Part information	<input type="checkbox"/> Action required
	<input type="checkbox"/> Mechanical	<input type="checkbox"/> Electrical	<input type="checkbox"/> Service manual revision
	<input type="checkbox"/> Paper path	<input type="checkbox"/> Transmit/receive	<input type="checkbox"/> Retrofit information
	<input checked="" type="checkbox"/> Other ()		<input type="checkbox"/> Tier2

Important Information about a New GJ Analysis Tool

- When a problem occurs in the field, please use the GJ analysis tool available from the Firmware Download Center. The tool is available for all GelSprinter products.

Model list:

G500/G700/G7500
 GX3000/GX3050N/GX5050N
 GX2500/GX7000
 GX3000S/GX3000SF/GX3050SFN

- Please use this tool to provide information for problem analysis, instead of the SMC report.