
| page 2 |
|---------|
| 4 |
| 4 |
| \aaa4 |
| page4 |
| , |
| page 6 |
| |
| page 8 |
| 7.0 |
| ge I () |
| |
| ge 12 |
| |
| ge 14 |
| |
| ge 16 |
| ge 8 |
| |

COPY QUICK GUIDE

This machine comes in two models which are referred to in this manual as Type 1 and Type 2. Check the inside front cover of the Copy Reference for the model you have before reading this guide.

Some limitations may apply to functions for details please refer to the Copy Reference.



Basics

How to Make Copies

Useful Functions

You can make copies without having to worry about paper size and image density since they are chosen automatically.

Auto Image Density

Automatically selects the image density.

Auto Paper Select

Automatically selects a suitable size of copy paper.

Set the original.

2

Make sure that

A:[Auto] is selected.


B:[100%] is displayed.

C: The **Auto Image Density** indicator is lit.

Tip


On the Exposure Glass





In the Document Feeder

Face - up



4

Press the **[Start]** key.

Enter the number of copies with the Number keys.

Never Forget!


Press the [Clear Modes] key to clear previously entered settings.




*To check selected modes, press the [Check Modes] key.



AB C



Copying to Different Copy



Paper Sizes

4

3

Press the [Start] key.


Select A4 copy paper with the $\textcircled{\ }$ keys.

In addition, the following functions are available:

Preset Reduce/Enlarge

Directional Size Magnification(mm)
Directional Magnification(%)

For details, please read the Copy Reference.




Duplex

Making 2-Sided Copies

The optional duplex unit is required to use this function.

In this situation ...



You wish to reduce output volume.

Use this function:



Use the Duplex function to copy onto both sides of paper.

Set the originals in the document feeder. Make sure you set them in the correct direction.

2


Press the [Duplex] key and make sure that [1 Sided □ → □] is selected.




If you get the orientation wrong, copies will be delivered upside down.



- 1. Identify the top of the original.
- 2. Set the original in the document feeder as shown below.





Don't set the original like this.

from 1-Sided Originals

1. Press the [Orientn.] key.



2. Select [Top to Bottom] with the 3. Press the [OK] key.






Select the orientation.



Press the [Start] key.





Tray 2

Copying onto Non-standard

Useful Functions

You can set the thin paper, thick paper, transparencies in tray 2.


Set the original.

2

Pull out tray 2 and insert the copy paper.

3

When you set the thin paper, thick paper transparencies, push the swtich-over lever to right.



4

Set the paper size selector to the new paper size.

^{*}If you cannot find your desired paper size, select " * ".
For details, see above right.

Paper from Tray 2




Setting Non-standard Size Paper in Tray 2

- Set the paper size selector to " * ".
- 2. Select Tray 2 with the key. Then press the [#] key.

| ⊖Ready | | | | Q't | y: 1 |
|---------|-------|------|--------|--------|--------------|
| Auto | A4 [] | A4 🗗 | A4 [] | A3 🗗 | |
| [1000.] | | | Select | with 🤄 | 0 ® - |
| [100%] | | | | | |

3. Press the [Pap.Size] key.



 Select your desired paper size with the

or

key. Then press the [OK] key. Go to step 6.

| Tray 2: 1 | 1/5 | Selec | t with 🐠 🕒 |
|----------------|---------|----------|------------|
| A3⊡₹ | B4JIS 🗗 | A4 🗗 | A4 🖵 |
| B5Jis ⊡ | B5JIS 🖟 | A5 🗗 | B6JIS □ |
| (TFrev. |)(↓Next |) Cancel | OK I |

If you cannot find your desired paper size, select [Custom Size:], then press the [OK] key.

| Tray 2: 5/5 | Select with ④ € |
|-------------------|------------------------|
| Custom Size: | |
| (†Prev.)(Nevt) | Cancel OK |

6. Enter the horizontal and vertical size. Then press the [OK] key.

| Tray 2: | Enter size, press 🤅 | • |
|-------------|---------------------|----------|
| Horiz.170mm | / Vert.117mm | |
| (148-432mm) | (100-297mm) | |
| | Cancel OK |] |

7. Press the [Pap.Type] key. Then select the paper type and press the [OK] key.




8. Press the [Exit] key.

Push the paper tray in until it stops.



Press the [Start] key.

*When you set standerd paper in Tray2, push the switch-over lever to left.




Combine

Combining Originals



You wish to save paper or cut down on filing space.



Use this function:


The machine can copy multiple 1-sided originals onto 1 sheet of copy paper.







Example:



Press the **Combine Series** key.

Set the originals in the document feeder.


Press the [Combine] key.




Tip

Setting the Originals in the Document Feeder

Originals reading from left to right



Originals reading from top to bottom



* Set the originals upside down.

into 1 Copy

Combining multiple 1-sided originals into one 2-sided copies 4 pages → 2-sided copy 16 pages → 2-sided copy 8 pages → 12

2-sided copy

2-sided copy


7
8

Front> <Back>

The optional duplex unit is required.


Select
[4 Orig. → []] with
the ③⑤ keys then
press the [OK] key.

Select the copy paper with the ③⑤ keys.




5

Press the **[Exit]** key.



Press the [Start] kev.



Stamp/page

Numbering Stamping Messages and

In this situation ...

You wish to have page numbers or a message (e.g.CONFIDENTIAL) printed on copies.






Use the Preset Stamp function. You can select the following phrases.

- CONFIDENTIAL COPY URGENT
- PRIORITY For your Information
- PRELIMINARY •For Internal Use Only.

To print page numbers, use the Page Numbering function.


You can choose from the following numbering formats:

• P1, P2 · · · • 1/5, 2/5 · · · • - 1 -, - 2 - · · ·



Set the originals.


Press the [Position] key.



Press the [Stamp] key.



Press the [Preset] key and Select your desired phrase. Then press the [OK] key.



Page Numbers on Copies

6

Press the [Page no.] key.

Stamp: Select item
Preset Stamp: CONFIDENTIAL

Preset Page no. Exit

Change stamp position with the ⊕ keys.Then press the [OK] key twice.

Select the format of the numbering with the keys. Then press the [OK] key.

Page Numbering: Select with **④⑤**P1,P2,... / <mark>1/5,2/5,...</mark> / -1-,-2-,...


Cancel OK

Enter start page, start No. and total pages with the Number Keys. Then press the [OK] key twice.

Print Page: Enter number Start Page: From Page 1 Start No.: 1 (Total Pages:<u>20</u>) Cancel OK


9

Press the [Start] key.



OHP Slip Sheet


Inserting OHP Slip



Set the originals in the document feeder.

Press the [OHP Slip] key.

Press the [Cover/OHP Slip Sheet] key.



Sheets



Before you use this function, you need to specify "Tray 2" or "Bypass" as the OHP transparencies tray.

For details, refer to the Copy Reference.


* If your machine does not have the bypass tray, only "Tray 2" can be selected.

If your machine has the bypass tray, "Bypass" is selected by default.

Set the OHP transparencies on the bypass tray or tray 2.

Press the [Start] key.


Select the slip sheet tray.



Stapling

Stapling While Copying


The optional finisher is required to use this function



Set the originals in the document feeder.

Press the **[Staple]** key.

Press the [Sort/Staple] key.





| Orientation of the original | Copies |
|-----------------------------|--------|
| R | R |
| R | R |

4

Press the **[OK]** key.


Enter the number of copies with the Number keys.


Press the

Press the [Start] key.

Features at a Glance

For details, please refer to the following pages in the Copy Reference.





Make copies of this manual and stick them on the wall.

