

1. Basics		\bigcirc
How to Make Copies	page.	_
2. Sorting/Sample Copy		1
Make a Sample Copy Before Copying a Large Volume	page.	4
3. Copy New Job Presetting the Next Job While Copying	page.	6
4. Stapling Stapling While Copying	page.	8
5. Combine		1 0
Stapling Combine 2-Sided Copies	page.	$\Gamma \cup$
6. Magazine Mode Making Copies into a Book-Like Format		
7. Batch Mode When the Original Stack is too Large to Fit in the Document Feeder		7 4
8. Document Server Printing Saved Documents as You Want	page.	7 /
9. Features at a Glance	page.	18

COPY QUICK GUIDE




Mojito UE-COVER.PM6 1 00.1.18, 11:16 AM

Make copies of the pages and put them up on the wall.



Put up the copies on the wall.





A293-7307 UE USA Printed in Japan

Basics

How to Make Copies

Useful Functions

You can make copies without having to worry about paper size and image density since they are chosen automatically.

●Auto Image Density

Automatically selects the image density.

●Auto Paper Select

Automatically selects a suitable size of copy paper.

•

Set the original.

2

Make sure that

- A: [Auto Image Density] is highlighted.
- B: [Full Size] (100%) is highlighted.
- C: [Auto Paper Select] is highlighted.


Tip

On the exposure glass

★Face down

Set the first page of the originals.






In the document feeder

★Face up

Set the originals in page order.



es


3

Enter the number of copies with the number keys.

4

Press the **[Start]** key.





If the panel display is too light or too dark

Adjust the brightness using the screen contrast knob in the left corner of the operation panel.

Sorting /

Sample Copy Make a Sample Copy Before Copy

In this situation ...

To avoid large numbers of waste copies, make one sample copy to check the output quality.



Use this function:

Using the Sample Copy function, you can check the output quality by making one sample copy first.

If the setting is correct, continue copying.



One sample copy

Make remaining copies.


(When making 4 copies, for example)

Set the originals in the document feeder.

Press the [Sort] key and select any other functions you require.

e.g., · Staple Duplex

 Punch Image Density Adjustment



fore Copying a Large Volume

Enter the number of copies with the number keys.

* If it is not acceptable, press the [Cancel] key and return to Step 2.

5

Check the Sample copy. If it is acceptable, press the [Resume] key.*

4


Press the [Sample Copy] key.

One sample set is copied.

The remaining copies are made.

Copy New Job

Presetting the Next Jo



2

Set the next copy job.

Press the [Copy New Job] Key.

ext Job While Copying

3


Set the originals.

4

Press the [Start] key.*

* The originals are scanned.

After the previous copy job is finished, the next job automatically starts.



Stapling

Stapling While Copying

The optional finisher is required to use this function.

In this situation ...

You don't have time to staple each copy set together by hand.



Use this function

Each copy set can be stapled together automatically.














You can set the original orientation separately in the following ways.

• Standard Orientation

Use this function for copying in the standard orientation.

• 90° Turn

Use this function when you want to copy onto A3, B4 or 11" x 17" paper.

	Original	Exposure glass	Document feeder
Standard Orientation	R		RR
90° Turn	E		A A

^{*} You can select the stapling position. For details, see the User Tools in the Copy Reference manual.

ing

-

Set the originals in the document feeder.

4


Press the [Start] key.

2

Select the stapling position based on the direction of the originals.

3

Enter the number of copies with the number keys.




Combine

Stapling Combine 2-9

The optional finisher is required to use this function.

In this situation ...

You wish to combine your originals and staple them automatically.



Use this function:

Using the Combine 2 Sided function and the Staple function, you can make two-sided copies and staple them together.




R R

front

nt back





Set the originals in the document feeder.

ont bac

Press the [Special Original] key.

the 🖳 ke

Press the wey, then press the [OK] key.




4

Press the [Duplex/Combine] key.

10

00.1.24, 0:51 PM

ne 2-Sided Copies




00.1.18. 11:19 AM

Mojito UE-10-11.PM6


Magazine Mode

Making Copies into a E



12

a Book-Like Format




4

Press the [OK] key.

5

Press the [Start] key.




Batch Mode

Mode When the Original Stack is too Larg


In this situation ...

You can set maximum 100 originals in the document feeder. If there are more than 100 originals...



Use this function:

Split your originals into stacks and use the Batch (SADF) mode.



Split your original into stacks, then set the first stack in the document feeder.

7

Press the [Batch (SADF)] key, then

press the [OK] key.

Press the [Special Original] key.


Tip

Split the originals into stacks of about 100 pages.



1st 2nd 3rd stack stack


Start with the first stack.



too Large to Fit in the Document Feeder

4

Enter the number of copies with the number keys, then press the [Start] key.




5

After the first stack of originals has been scanned, set the next stack of originals.*

* If the next stack of originals is not fed automatically, press the [Start] key.


6

After the final original has been scanned in, press the [#] key.



Document Server


Server Printing Saved Docu me



Saved Documents

Prepare the documents you want to save.

- ① Press the [Document Server/New Job] key.
- ②Press the [Scan Originals] key.
- **3** Set the originals in the document feeder.
- 4 Press the [Start] key.



* You can edit the filenames of documents stored in the Document Server or set the password. For details, see the Copy Reference manual.

cu ments as You Want

Press the [Document Server/New Job] key.

2

Select the document you want to print.

S e [Print


Press the [Print Setting] key, then make sure the printing setting.

the numl

Enter the number of copies with the number keys.


5

Press the [Start] key.




Features at a Glance

For details, see the following pages in the Copy Reference manual.



00.1.24, 0:57 PM

UE (USA) A293



ZBOX010t

1 Sided 16 Pages → Combine 2 Side | ⇒ Page 125

1 2 3 4 5 6 7 8 2 Sided 16 Pages → Combine 2 Side ⇒ Page 135

1 2 3 4 5 6 7 8 Multi → 2 Sided | ⇒ Page 143

⇔

00.1.24, 0:57 PM

Side ⇒ Page 130

2 3 4 6 7 8