

## Quick Reference Copy Guide

# ➡ Please put this guide above your machine ⬅

\*The shape of the machine, screen displays, procedures, and titles in references vary depending on the machine you are using. Also, not all functions are available on all machines.

### Tips

#### Paper Size



#### Paper Size

You can check the paper size using the scale on the exposure glass.

#### Auto Image Density

Dark texture originals will be copied so that background will not be reproduced.

#### Auto Paper Select

Selects a suitable size of paper automatically.


### How to make Copies... (Placing Originals, Paper Specifications and Adding Paper, Basic Copying)

1 Press the [Home] key on the top left of the control panel. Flick the screen to the left, and then press the [Copier] icon on the Home screen 4.


2 Press [Reset].

3 Place the originals.

- Exposure Glass (Face down)



- Auto Document Feeder (Face up)



4 Make desired settings.

5 Enter the number of copies.

6 Press [Start].

### How to select a color mode... (Color Copying)


1 Select a color mode.



### How to Reduce/Enlarge... (Basic Copying)

#### Auto Reduce/Enlarge

1 Press [Auto Reduce / Enlarge].



2 Select the paper size.

3 Place the originals, and then press [Start].

#### Preset Reduce/Enlarge

1 Press [Reduce / Enlarge].



2 Select a ratio, and then press [OK].



3 Place the originals, and then press [Start]. (Paper size is selected automatically.)

1. [Home] key  
Press to display the [Home] screen.
2. Display panel
3. [Reset]
4. Energy Saver
5. Main power indicator

6. Media access lamp
7. Media slots
8. [Stop] key  
Press to stop a job in progress, such as copying, scanning, faxing, or printing.
9. [#] (Enter key)
10. [Sample Copy]

11. [Start]  
Press to start copying, printing, scanning, or sending.
12. [C] (Clear key)  
Press to delete a number entered.
13. Number keys
14. [Simplified Scrn.]

15. [Interrupt mode]
16. [Recall/Program/Change Program]  
Press to register frequently used settings, or to recall registered settings.
17. [Check Status] key
18. [Menu] key
19. [Return] key



### How to save paper... (Basic Copying)

1 See if original is 1-sided or 2-sided (duplex).

2 Press [Dup./Combine/Series].

3 Select the original and copy types and/or the orientation.


4 Place the originals, and then press [Start].



#### Duplex


##### 1-Sided → 2-Sided

Copies two 1-sided pages on one 2-sided page.



##### 2-Sided → 2-Sided


Copies one 2-sided page on one 2-sided page.



#### Combine


##### 1-sided Combine

Copies multiple 1-sided or 2-sided originals on one side of copy paper.




##### 2-sided Combine

Copies multiple 1-sided originals on two sides of copy paper.



Copies multiple 2-sided originals on two sides of copy paper.



! For more functions on Combine, see "Basic Copying", Copy/ Document Server.

### How to finish your document... (Basic Copying)

#### Staple

1 Press [Finishing].


2 Press [Finisher] when the key is displayed.

3 Select one of the stapling positions (Copies will be sorted automatically).

4 Press [OK].

5 Enter the number of copies.

6 Place the originals, and then press [Start].



#### Punch

1 Press [Finishing].

2 Press [Finisher] when the key is displayed.

3 Select one of the punch hole positions (Copies will be hole punched).

4 Press [OK].

5 Enter the number of copies.

6 Place the originals, and then press [Start].

! Staple and Punch can be done at the same time.

! Availability of finishing depends on your configuration.

### Document Server (Basic Copying)

#### Why use it...

- To store often used documents centrally and print on demand.
- To reduce network load.

#### How to use in copy mode...

1 Press [Store File].



2 Enter a user name, file name, or password if necessary.



3 Specify a folder in which to store the document if necessary.

4 Press [OK].

5 Place the originals.

6 Make the scanning settings for the original.

7 Press [Start].

The machine stores scanned originals in memory and makes one set of copies.

To find your document, press the [Home] key on the top left of the control panel, and press the [Document Server] icon on the screen.



- ! For more functions on Document Server, see "Document Server", Copy/ Document Server.

### Simple Screen

When you press [Simplified Scrn.], the screen changes to the simple screen. Letters and keys are displayed at a larger size, making operations easier. Only the main functions can be used.

### Advanced features (Basic Copying, Advanced Copying)

#### Reduce/Enlarge

- Zoom: You can specify the reproduction ratio in increments of 1%.
- Magnification: You can specify the horizontal and vertical reproduction ratios, individually.

#### Series Copies

- Separately copies the front and back of a 2-sided original onto two sheets.

#### Booklet/Magazine

- Copies two or more originals in page order.

#### Edit/Stamp

- Image Repeat/Double Copies: The original image is copied repeatedly.
- Centering: Moves image to the center.
- Erase: Erases the center and/or all four sides of the original image.
- Stamps: Copies with the date, page numbers, etc.
- Cover/Slip Sheet
  - Covers: Create cover sheets.
  - Designate: Copies certain pages of the original onto designation sheets.