


Quick Reference Scanner Guide

➡ Please put this guide above your machine ⬅

1. Display panel
 - 1.1 Destination field
 - 1.2 E-mail icon
 - 1.3 E-mail/Folder
 - 1.4 [Check Modes]
 - 1.5 Destination list
 - 1.6 [Text] [Subject] [Security] [Sender Name] [Receipt. Notice] [Select Stored File]
 - 1.7 [Send File Type / Name]
 - 1.8 [Reg. No.] [Manual Entry] [Recent]
2. Main power indicator
3. Operation switch
Press this to turn the machine on/off.
4. [Energy Saver] key
Press this to switch the machine into or out of Energy Saver mode.
5. [Login/Logout] key
6. [User Tools/Counter] key
7. [Program] key
8. [Interrupt] key
9. [Simplified Display] key
10. [Clear Modes] key
11. [Start] key
Press this to begin scanning, storing, or sending.
12. [Clear/Stop] key
- clears an entered numeric value
- stops scanning
13. [#] key (Enter Key)
14. Number keys
15. Alert indicator
16. Data In indicator
17. Indicators
18. Function keys
Press the [Scanner] key to activate these keys.



* The facsimile function is standard on some models.

This button needs to be selected as a first step.

You can also fax on this machine!
Please ask your service representative for this option.

How to scan...

Available scan functions:

- 1 Scan to E-mail
- 2 Scan to Folder (SMB/FTP/NCP)
- 3 Scan Using WSD (Web Services on Devices)
- 4 Store to Hard Disk
- 5 Save to Removable Memory Device
- 6 Scan to Delivery Server
- 7 Scan via TWAIN Driver

For details about 1, 2, 3, 4, and 7, see *Scanner Reference* on the supplied CD-ROM.


How to use Scan to E-mail/ Scan to Folder...

(1. Sending Scan Files by E-mail)
(2. Sending Scan Files to Folders)

- 1 Press the [Scanner] key.
- 2 Press the [Clear Modes] key.
- 3 If the network delivery scanner screen appears, switch to the E-mail screen or Scan to Folder screen.
- 4 Place the originals and configure the necessary settings such as original size and orientation.

- 5 Select destination(s).
In total, up to 500 destinations can be specified.
For scan to e-mail:
Before selecting the destination, be sure to select [To]. When necessary, select [Cc] or [Bcc] and destination(s).
- 6 If necessary, press [Send File Type / Name] to specify settings such as file name and file format.
- 7 **For scan to e-mail only**
Specify the e-mail sender.
Depending on the security settings, the logged-in user may appear in the [Sender Name] field.

- To specify the e-mail sender, press [Sender Name].
- Select a sender.
- Press [OK].
- For reception confirmation e-mail, press [Receipt. Notice].



- 8 **For scan to e-mail only**
Enter a subject line if necessary.
 - Press [Subject].
 - Enter the subject.
 - Press [OK].
- 9 Press the [Start] key.

How to save to the machine's hard disk...

(4. Storing Files Using the Scanner Function)

- 1 Press the [Scanner] key.
- 2 Press the [Clear Modes] key.
- 3 Make settings for storing scanned data files:
- Press [Store File] and [Store to HDD].
- 4 Specify the file information: user name, file name, and password. Press [OK].
- 5 Place the originals and configure the necessary settings via [Original Feed Type].
- 6 Configure the basic settings (original type, resolution, etc.) via [Scan Settings].
- 7 Press the [Start] key.

For details about saving to removable memory devices, see 5. Saving Scan Files on a Removable Memory Device, *Scanner Reference* on the supplied CD-ROM.


Why use it?

To store scanned files in the hard disk of the machine for later (shared) use. (See *Scanner Reference*.)

Displaying a list of files stored on the machine's hard disk

(4. Storing Files Using the Scanner Function)

- 1 Press the [Scanner] key.
- 2 Press [Select Stored File].
The list of stored files is displayed.



Registering an E-mail destination...

(Network and System Settings Reference
5. Registering Addresses and Users for Facsimile/Scanner Functions)

- 1 Press the [User Tools/Counter] key.
- 2 Press [System Settings].
- 3 Press [Administrator Tools].
- 4 Press [Address Book Management].
- 5 Check that [Program / Change] is selected.
- 6 Press [New Program].
- 7 Configure the user details.
- 8 Press [E-mail].
- 9 Press [Change], which is on the right side of the e-mail address.
- 10 Enter the e-mail address, and then press [OK].
- 11 Press [OK].

For details about registering folders, see 5. Registering Addresses and Users for Facsimile/Scanner Functions, *Network and System Settings Reference*.